




COOKTOP PARTS

For Model: RF360BXYW1, RF360BXYN1
(White) (Almond)

30" ELECTRIC
FREESTANDING
SELF CLEAN RANGE



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Model: RF360BXYW1, RF360BXYN1
(White) (Almond)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|---|---------|-----------------------------------|
| 1 | 3183959 | Latch Asm Complete W/Wire Harness |
| | 343641 | Screw, 10-16 x 1/2 (2) |
| 2 | 308185 | Safety Switch |
| | 98106 | Screw (2) |
| 3 | 309245 | Insulator, Switch |
| 4 | 313035 | Shield, Latch Terminal |
| | 309258 | Screw, 6 x 3/8B (2) |
| | 308422 | Screw (2) |
| 5 | 3169081 | Handle, Latch |
| | 155023 | Screw, 8-18 x 1/4 |
| 6 | 3148684 | Knob, Latch |
| 7 | 3169186 | Box, Burner |
| | 309112 | Screw, 10A x 3/8 (4) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

| | | |
|----|---------|------------------------|
| 8 | 307973 | Shield, Wiring |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 9 | 3148659 | Rod, Cooktop |
| 11 | 307965 | Bracket (2) |
| | 343641 | Screw (4) |
| 12 | 307966 | Pin, Cooktop (2) |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 13 | | Cooktop |
| | 3170981 | White |
| | 3170982 | Almond |
| | 690989 | Screw, 10-32 x 1/2 |
| 15 | 308605 | Strain Relief |
| | 343641 | Screw, 10-16 x 1/2 |
| 16 | 312606 | Receptacle |
| | | Clip (4) |
| | 313808 | Screw (4) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

| | | |
|----|---------|----------------------|
| 18 | | Pan-Combination |
| | 3169204 | 6" (2) |
| | 3169205 | 8" (2) |
| 19 | 660529 | Unit, Surface |
| | | 6" L.F. & R.R. |
| | 660533 | Unit, Surface |
| | | 8" R.F. & L.R |
| | | (Includes Illus. 20) |
| 20 | 309195 | Medallion (4) |
| 23 | 3148790 | Hold Down Clip (4) |
| | 814102 | Nut (4) |
| | 487887 | Screw (4) |

FOLLOWING PARTS NOT ILLUSTRATED

LITERATURE PARTS


| | |
|------------|---------------------------|
| LIT3147400 | Installation Instructions |
| LIT3183707 | Wiring Diagram |
| LIT3169015 | Use & Care Guide |
| LIT885028 | Repair Parts List |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: RF360BXYW1, RF360BXYN1

(White) (Almond)



**Illus. Part
No. No. DESCRIPTION**

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|----|---------|-------------------------------|
| 1 | 313191 | End Trim R.H. |
| | 313190 | End Trim L.H. |
| | 309112 | Screw, 10A x 3/8 (2) |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 2 | 3150441 | End Cap R.H. |
| | 3150442 | End Cap L.H. |
| | 254225 | Screw, 8BT x 1/4 (4) |
| 4 | 3148564 | Switch, Rocker |
| 6 | 309822 | Timer Motor |
| 10 | 3183063 | Timer, Clock (Includes #6) |
| | 246132 | Screw, 8A x 3/8 (2) |

**Illus. Part
No. No. DESCRIPTION**

| | | |
|----|---------|----------------------------------|
| 11 | 313513 | Glass, Timer |
| 15 | 3183814 | Panel, Control |
| | 312604 | Screw, 8-18 x 5/8 (4) |
| | 690989 | Screw, 10-32 x 1/2 |
| 17 | | Switch, Infinite |
| | 3148951 | 6" (2) |
| | 3148954 | 8" (2) |
| | 311865 | Screw, 8-32 x 1/4 (8) |
| 18 | 3148419 | Switch, Selector (5 Position) |
| | 3150344 | Screw, 8-32 x 1/4 (2) |
| 19 | 3148933 | Thermostat, Oven |
| | 311932 | Screw, 6-32 x 1/4 (2) |


**Illus. Part
No. No. DESCRIPTION**

| | | |
|----|---------|--|
| 20 | 314031 | Light, Indicator (Oven Unit) (Includes Illus. 26) |
| 21 | 3150662 | Light, Indicator (Surface Unit) (Includes Illus. 26) |
| 22 | 3183118 | Knob (4) (Infinite Switch) |
| 23 | 3183103 | Knob (Temp) |
| 24 | 313570 | Tube Clip |
| 25 | 313195 | Rear Cover |
| | 343641 | Screw, 10-16 x 1/2 (8) |
| 26 | 313101 | Lens, Amber (2) |
| 27 | 3169182 | Knob (3) (Timer) |
| 28 | 313608 | Shield, Glass (2) |
| | 246132 | Screw, 8A x 3/8 (2) |
| 29 | 3183115 | Knob (Selector) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: RF360BXYW1, RF360BXYN1
(White) (Almond)



Illus. Part
No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|---|---------|------------------------|
| 1 | | Main Chassis |
| | 330086 | White |
| | 330090 | Almond |
| | 690989 | Screw, 10-32 x 1/2 |
| | 343641 | Screw, 10-16 x 1/2 (2) |
| 2 | 238614 | Bumper, Cooktop (2) |
| 3 | 312701 | Leg Leveling (4) |
| 4 | 3176698 | Frame, Front |
| | 343641 | Screw (Sides) |
| | 3150537 | Screw (Top) |
| 5 | 307985 | Pin, Hinge |
| 6 | 3169251 | Seal, Door |
| 7 | 308306 | Pushnut |

Illus. Part
No. No. DESCRIPTION

| | | |
|----|---------|------------------------|
| 8 | 3176710 | Hinge, R.H. |
| | 3176711 | Hinge, L.H. |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 9 | 3176611 | Oven (30" Pyro) |
| | 311056 | Screw (2) |
| | 3150537 | Screw |
| 10 | 3150505 | Socket, Lamp |
| 11 | 311255 | Bulb, Oven Light |
| 15 | 311220 | Bracket, Oven Mounting |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 16 | 3169108 | Vent, Oven |
| | 307748 | Screw, 10A x 1/2 (2) |
| 17 | 314209 | Switch, Broil |
| 18 | 314210 | Switch, Bake |
| 19 | 3176709 | Channel, Arm (2) |
| 20 | 307986 | Hinge Pin (2) |
| 21 | 307594 | Ring, Retainer (2) |

Illus. Part
No. No. DESCRIPTION

| | | |
|----|--------|------------------------|
| 22 | 308127 | Spring, Oven Door (2) |
| 23 | 308125 | Anchor, Spring (2) |
| 24 | 313196 | Support, L.H. Channel |
| | 313197 | Support, R.H. Channel |
| | 343641 | Screw, 10-16 x 1/2 (4) |
| 25 | 308535 | Button Plug |
| 26 | 312804 | Block, Balance |
| | 340184 | Screw |
| 27 | 313382 | Clip, Therm Bulb (2) |
| 29 | 309111 | Snubber, Door (2) |

Following Parts Not Illustrated


| | |
|---------|-----------------------|
| 3169093 | Insulation, Wrap |
| 3169094 | Insulation, Oven Back |
| 814148 | Anti-Tip Kit |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: RF360BXYW1, RF360BXYN1

(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: RF360BXYW1, RF360BXYN1
(White) (Almond)

| Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION |
|---|--|--|
| NOTE: The screws and nuts required to attach a part are listed immediately following that part. | | |
| 1 307981 Bracket, Mounting (2) | 4 661170 Unit, Bake (240V) 308180 (Alt.) 313827 (Alt.) | 8 3150190 Bracket, Service 343641 Screw, 10-16 x 1/2 (2) |
| 2 3149255 Rail R.H. (Includes Illus. 3) | 312309 Unit, Bake (208V) 3150532 Screw (2) | 10 3148975 Cover, Rear 343641 Screw, 10-16 x 1/2 (7) |
| 3149256 Rail L.H. (Includes Illus. 3) | 5 660579 Unit, Broil 311714 (Alt.) 311713 (Alt.) | 11 307972 Cover, Service 343641 Screw, 10-16 x 1/2 (2) |
| 343641 Screw, 10-16 x 1/2 | 312308 Unit, Broil (208V) 3150532 Screw (2) | 12 3169076 Pan, Broiler |
| 3 3149257 Glide, Front (2) | 6 3184673 Terminal Block | 13 3147563 Rack, Broiler |
| 307748 Screw (2) | 98884 Screw, 10-16 x 1 (2) | 14 308173 Rack, Oven (2) |
| | 112432 Nut (6) | 16 311982 Plate, Cover (2) |
| | 7 308498 Ground Strap | 3150532 Screw, 10A x 1/2 (2) |
| | 313660 Clip | |
| | 690989 Screw, 10-32 x 1/2 | |

OPTIONAL PARTS NOT INCLUDED

| Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION |
|--|---|--|
| <u>SPLICING WIRES--25FT. LENGTH</u> | <u>PAINT, TOUCH-UP (1/2oz.)</u> | <u>PAINT, BULK (1 qt.)</u> |
| 242828 Wire, Black 12 Ga. 150°C | 72017 White | 799344 White (Uncut) |
| 242820 Wire, Black 14 Ga. 150°C | 72107 Almond | 978883 Almond (Uncut) |
| 242821 Wire, Blue 14 Ga. 150°C | 72109 New Avocado | 261891 Harvest Gold (Uncut) |
| 242822 Wire, Brown 14 Ga. 150°C | 72108 Coffee | 285367 Toast (Uncut) |
| 242830 Wire, Brown 14 Ga. 200°C | 72110 Harvest Gold | 285368 Platinum (Uncut) |
| 242823 Wire, Green 14 Ga. 150°C | 72112 Toast | |
| 242824 Wire, Orange 14 Ga. 150°C | 72113 Platinum | |
| 242829 Wire, Red 12 Ga. 150°C | * * 511873 White Porcelain (2 Oz.) | |
| 242825 Wire, Red 14 Ga. 150°C | | <u>REFINISHING MATERIAL</u> |
| 242831 Wire, Red 14 Ga. 200°C | <u>PAINT, PRESSURIZED SPRAY (13 oz.)</u> | 799832 Kit, Porcelain Repair (White) |
| 242826 Wire, White 14 Ga. 150°C | 350930 White | 242756 Touch-Up Self-Clean (1/2 Pt.) |
| 242827 Wire, Yellow 14 Ga. 150°C | 350956 Almond | 261582 Grease |
| 242832 Wire, Yellow 14 Ga. 200°C | 261888 New Avocado | |
| | 261886 Coffee | <u>ACCESSORY PARTS</u> |
| | 261890 Harvest Gold | 241430 Foil, Aluminum Oven (18" x 25') |
| | 285365 Toast | 677973 Manual, Range (Do-It-Yourself) |
| | 285366 Platinum | |
| | 285006 Superior Black | |
| | 206922 Primer (White) | |
| | 206925 Leveler (Thinner) (2 oz.) | |


* * Note: Cooktop Surface is Porcelain; All Other Panels are Painted Surfaces.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: RF360BXYW1, RF360BXYN1

(White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|----|---------|----------------------|
| 1 | 3172219 | Liner, Oven Door |
| | 307748 | Screw (2) |
| | 3148443 | Screw (6) |
| 2 | 3148160 | Retainer, Insulation |
| | 3148443 | Screw (4) |
| 3 | 3148182 | Bumper, Door (4) |
| 4 | 3148186 | Panel, Glass |
| 5 | 3148228 | Handle, Door |
| 6 | 3148223 | Door Top |
| | 307748 | Screw (2) |
| 7 | 3148282 | Clip, Handle (2) |
| | 355515 | Screw (4) |
| 8 | 3148235 | Frame, Door |
| | 307748 | Screw (3) |
| | 355515 | Screw (4) |
| 9 | 307980 | Glide, Rear (2) |
| | 313349 | Screw, 8-18 x 1/2 |
| 10 | | Panel, Drawer |
| | 3150676 | White |
| | 3150677 | Almond |
| | 313349 | Screw, 8-18 x 1/2 |
| 11 | | Handle, Snap-In |
| | 3150612 | White |
| | 3150613 | Almond |
| 12 | 327887 | Drawer, Utility |
| 13 | 309329 | Protector (2) |
| 14 | 3147951 | Insulation |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: RF360BXYW1, RF360BXYN1
(White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------------------------|
| 1 | 3149881 | Wiring Harness (Surface Unit) |
| 2 | 3169152 | Wiring Harness (Oven) |
| 3 | 3183962 | Wiring Harness (Lock Switch) |
| 5 | 330031 | Receptacle |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST